


BY SCOUR



Section 3: Natural bed & scour protection structures at banks. Significant signs of scour and failure of structures along reach.

RECOMMENDED OPTION: Widen channel bed and regrade eastern bank. Replace existing scour protection on western bank. Widened section to include rock weirs, meanders and green engineering.

> SECTION 3 NOT TO SCALE

## Appendix 1B